

PTCS Heat Pump Thermostat Support Sheet

Manufacturer: Carrier Infinity Touch Control

Thermostat Models: SYSTXCCITW01-A, SYSTXCCINTN01-A, SYSTXCCITC01-A, SYSTXCCITC01-B

The Carrier Infinity Touch is a communicating thermostat compatible with Carrier units only

Caution: On the first screen when entering installer set-up mode (service menu), always press "Cancel" rather than "Save" to avoid changing original installer settings.

Is a Password Required? **NO**

1. How to enter installer set-up (Service Menu)

- From the Home screen, press "Menu" in the lower right corner
- An "Options" screen appears with 8 icons. Press the down arrow in the lower right corner to scroll to the second page of options
- Press and HOLD the "Service" icon (a picture of a baseball cap) located in the upper left corner for 10 seconds until it turns green



2. Determine system characteristics through T-Stat

- From the Service menu (accessed by pressing and holding the service baseball cap icon) press "Service Information"
- Select "Service Information" from the "Options" screen
- Scroll down to "Model/Serial numbers" and press "Enter". The system information will be displayed.
- Press "Back" or "Done" to exit the system information screen

3. Check Compressor Lockout settings - *Carrier refers to this feature as "Heat Source Lockouts- HP Lockout"*

- From the Service menu (accessed by pressing and holding the service baseball cap icon) press "SETUP"
- From the Setup menu, select "Heat Source Lockouts"
- Heat Pump Lockout (compressor lockout) is displayed on the left. Verify it is set to "below" 5 degrees, or "None". This setting is adjustable from 5-55 degrees
- Press "Cancel" to return to the previous screen without changing any settings
- Do not hit the save button at any time**

4. Check Strip Heat settings - *Carrier refers to this feature as "Heat Source Lockouts - Electric Heat Lockout"*

- From the Service menu (accessed by pressing and holding the service baseball cap icon) press "SETUP"
- From the Setup screen, select "Heat Source Lockouts"
- Electric Heat/Furnace Lockout (strip heat or backup heat lockout) is displayed on the right. Verify it is set to a maximum of 35 degrees. This setting is adjustable from 5-55 degrees.
- Press "cancel" to return to the previous screen without changing any settings
- Do not hit the save button at any time**

PTCS Heat Pump Thermostat Support Sheet

Manufacturer: Carrier Infinity Touch Control

Thermostat Models: SYSTXCCITW01-A, SYSTXCCINTN01-A, SYSTXCCITC01-A, SYSTXCCITC01-B

The Carrier Infinity Touch is a communicating thermostat compatible with Carrier units only

5. Access Test Mode for testing system at full capacity

- a. From the Service menu (accessed by pressing and holding the service baseball cap icon) press "Check Out"
- b. Beside "Heat Pump", select "Heating" or "Cooling" depending on the desired test
- c. On all systems except for the Greenspeed series, select the amount of time you wish to run test and push the up arrow to the highest heating or cooling stage available
- d. On the Greenspeed series, select the amount of time you wish to run the test and push the up arrow until it reads 100%
- e. Select "Start"
- f. Wait and listen to ensure that the system sounds as if it has ramped up to full fan speed. This may take a few minutes depending on the indoor unit characteristics
- g. Wait at least 10 minutes before taking static pressure readings and inserting flow plate for Trueflow plate test
- h. Wait at least 20 to 25 minutes before doing temperature split readings for refrigerant test. The longer the system is allowed to run, the more likely it will reach a steady state

6. Exit Service Menu

- a. To exit the Service menu, press "DONE" in the bottom right hand corner of the screen

7. Exit Set-Up Menu

- a. Depending on which Setup menu screen you are on, press "BACK" until you reach the main service menu screen
- b. Press "Exit" and you will return to the home screen

Caution: On the first screen when entering installer set-up mode (service menu), always press "Cancel" rather than "Save" to avoid changing original installer settings.

Resources: Carrier Support: 1-800-227-7437

Sources: Installation Manual: <http://www.utcccs-cdn.com/hvac/docs/1009/Public/09/SYSTXCCITC-02SI.pdf>