# **PTCS Heat Pump Thermostat Support Sheet**

Manufacturer: Ecobee

Thermostat Models: Ecobee 3 Lite, Ecobee 4, Ecobee 5

### Is a Password Required? NO

## 1. Determine System Characteristics Through T-Stat

- a. Press "MENU" in the lower left corner of the home screen
- b. Press "ABOUT" to display basic system characteristics such as software version

#### 2. Check Compressor Lockout settings

- a. Press "MENU" (the three lines in the lower left corner of the home screen)
- **b.** Press "SETTINGS" to access the installation settings menu
- c. Press "INSTALLATION SETTINGS"
- d. Press "THRESHOLDS"
- e. Press "COMPRESSORMINTEMPERATURE
- f. Set to "DISABLED" or ≤5F



### 3. Check Strip Heat settings

a. From the threshold menu listed in steps 3a-3d scroll down to "AUX HEAT MAX OUTDOOR TEMPERATURE" The temperature should be set to ≤35F

#### 4. How to Enter System Test Mode

- a. Press "MENU", the three lines in the lower left corner of the home screen
- **b.** Press "SETTINGS" to access the installation settings menu
- c. Press "INSTALLATION SETTINGS"
- d. Press "TEST EQUIPMENT"
- e. Choose heating or cooling mode for testing
- f. Simply back out of that menu once testing is complete to cancel the test mode

**Resources:** Ecobee Customer Support 1-877-932-6233, <a href="https://support.ecobee.com/hc/en-us/articles/360002020552-Threshold-settings-for-ecobee-thermostats">https://support.ecobee.com/hc/en-us/articles/360002020552-Threshold-settings-for-ecobee-thermostats</a>

